

Eleven Golf Adjustable Hosel Guide

Our Eleven Golf Driver and Mini-Drivers utilise a **triple collar adapter**, which takes adjustability to the next level. Offering maximum flexibility without ever needing to rotate the shaft. Perfect for golfers who are looking to dial-in that perfect swing, this game-changing feature ensures seamless loft adjustments while maintaining optimal alignment.



See below the adjustment chart and corresponding adapter configurations, to dial-in that perfect swing.

N = Neutral Face Angle	D = Draw Bias Face Angle
LN = Lie Neutral	L+ = Lie Plus (1 degree up)
S = Standard Loft	-1 = Minus 1 Degree Loft
+1 = Plus 1 Degree Loft	+2 = Plus 2 Degree Loft

Triple Collar Adapter Settings (1/2)			
S/LN/N	S/LN/D	S/L+/N	S/L+/D
Standard Loft, Lie Neutral, Neutral	Standard Loft, Lie Neutral, Draw	Standard Loft, Lie Plus, Neutral	Standard Loft, Lie Plus, Draw
D/LN/-1	D/LN/+2	D/L+/-1	D/L+/+2
Draw, Lie Neutral, Loft -1	Draw, Lie Neutral, Loft +1	Draw, Lie Plus, Loft -1	Draw, Lie Plus, Loft +2

Triple Collar Adapter Settings (2/2)			
+1/LN/N	+1/LN/D	+1/L+/N	+1/L+/D
Loft +1, Lie Neutral, Neutral	Loft +1, Lie Neutral, Draw	Loft +1, Lie Plus, Neutral	Loft +1, Lie Plus, Draw
N/LN/-1	N/LN/+2	N/L+/-1	N/L+/+2
Neutral, Lie Neutral, Loft -1	Neutral, Lie Neutral, Loft +2	Neutral, Lie Plus, Loft -1	Neutral, Lie Plus, Loft +2

*Please note that these drivers are shipped with the heads off and require partial assembly. To attach the head, you'll simply need to slot the head into the hosel. Then using the tool that was included with your order, tighten the head into the shaft until the tool begins to 'click'. Its best to adjust the configuration rings to your desired set up first.